




BR48R Relays V1 2025



Relay Identification	Relay #1	Relay #2	Relay #3	Relay #4
Relay Position	Wire #	Wire #	Wire #	Wire #
85	07	22	09	28/28a
86	-6/-5	-5/-4	-4/-3	-3/-2
30	41	23	20	12
87A	E15			
87		24	21	-1/-2

Relay Identification	Relay #5	Relay #6	Relay #7	Relay #8	Relay #T	SG
Relay Position	Wire #	L pin				
85	30	05/5a	08	38	5a	33
86	-7/-6	-8/-7	-9/-8	-10/-9	-10/-11	B pin
30	19a/19b	01	B08A	19b/19c	03	32
87A			03	37		E pin
87	31	06			36	-11

Relay Pin Locations
As Viewed From The
Wire Side of the Socket

