



### Fuse Position



	Position	Description	Rating
1	FU1	All Power	30A
2	FU2	Working Lights	20A
3	FU3	Water Pump	10A
4			
5			
6			

### Fuse Wiring

Wire Number	Jack
06	A
23	B
20	C
	D
	E
	F



Jack	Wire Number
1	19a/19g/19h
2	1
3	1 19w/19x
4	1
5	1
6	1